

Installation

Please power off before installing the product.

1. Take out the inner and outer covers of the lamps separately.
2. Determine the position of punching holes on the ceiling. Determine the fixing hole position of the outer cover of the lamp on the ceiling with a marking pen, punch the expansion screws at the hole position, punch the self-tapping screws without locking screws.
3. Align the three holes of the outer cover with the screws and rotate the cover to lock the screws.
4. Connect the inner and outer covers of the luminaire with the safety cord and earth wire (plug and play)
5. Unplug the external power supply from the ceiling and connect the power cord.
6. Tilt the inner cover of the luminaire 45° into the inside of the outer cover of the luminaire, and flatten the inner cover inside the outer cover.

Installation Notes

